## CARAVAN PRE-TRIP TOWING CHECKLIST



MUST-DO'S BEFORE HITTING THE ROAD

PRE-TRIP INTERIOR CHECK	
Secure all loose items and luggage within your Titanium Caravan.	
Close and secure all internal doors and cupboards, including the refrigerator door.	
Disconnect the TV, take it off the bracket and secure it.	
Secure vents, hatches, skylights, and windows. Leave window shades open.	
Turn off the water pump, inverter, gas and hot water system.	
Turn off the 12v switch (main black switch near door).	
Lock the door, and confirm it's secure.	
PRE-TRIP EXTERIOR CHECK	
Lock all external storage hatches and compartments.	
Turn off your gas bottles and close the green valve.	
Ensure your awning is locked and secured.	
Retract the entrance step and stabiliser legs.	
If applicable, check that your airbags are at the correct height as per manufacturer's specifications.	
CARAVAN HITCHING	
Ensure the caravan is correctly coupled to the tow vehicle and you have locked the pin on your Cruisemaster hitch.	
Crisscross safety chains and securely connect to tow bar.	
Connect the 12 pin cable, breakaway cable, Safety Dave cable and all nessecary Anderson plugs to the tow vehicle.	
Disengage the handbrake.	
Raise and secure the jockey wheel.	
WHEELS	
Ensure all wheel nuts are correctly tightened (Use a torque wrench and tighten to 160nm).	
Re-tighten wheel nuts at intervals (first 100kms, then every 250kms).	
Check and maintain correct tyre pressures according to the tyre sidewall.	
LOADED MASS	
The loaded mass of your caravan must not exceed:	
The maximum capacity of the ball weight.	
The GVM specified by the towing vehicles manufacturer.	
The GCM specified by the towing vehicles manufacturer.	